




Tag Printer Configuration

Table of Contents

Introduction.....	2
Citizen CLP 2001 (String)	2
CITOH S4 (String).....	2
DataMax 4203 (String)	2
DataMax 4203 (Dumbbell) (With Black Mark)	3
Godex TT361R (Either)	3
Godex (Either)	3
ZipTape ZT1300 (Either).....	3
Zebra S4M (Dumbbell) (No Black Mark)	3
Zebra Stripe 600 TT361R (Either).....	4

Introduction

The Edge will work with many different tag printers and tag types. This document outlines the configuration settings recommend for each one; your needs may vary slightly.

Style	Visual
Dumbbell	
String	
String w/companion (an Edge proprietary tag allowing you to print two tags for each item)	

To access printer configuration, go to **Administrative ▶ Configuration** and scroll down to the tag printer to be configured.

Citizen CLP 2001 (String)

Tag Printer 1 Settings	
TagAdjustGap	-13
TagAdjustLeft	5
TagAdjustTop	0
TagDPI	203
TagPrinter	\\\USB\VID_050D&PID_0002#5&3256b5d&0&3#\{a5dcbf10-6530-11d2-90ff-00c04fb951ed}
TagPrinterBurnSetting	20
TagPrinterType	Citizen
TagRetries	30
TagSensorMode	Default
TagStopPosition	0

CITOH S4 (String)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	5
TagAdjustTop	0
TagDPI	203
TagPrinter	Ipt3:
TagPrinterBurnSetting	20
TagPrinterType	CITOH
TagRetries	30
TagSensorMode	Edge_of_Label
TagStopPosition	0

DataMax 4203 (String)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	5
TagAdjustTop	0
TagDPI	203
TagPrinter	
TagPrinterBurnSetting	15
TagPrinterType	Datamax
TagRetries	30
TagSensorMode	Edge_of_Label
TagSpecialBeginBatch	
TagSpecialEach	
TagSpecialEndBatch	
TagStopPosition	0

DataMax 4203 (Dumbbell) (With Black Mark)

Tag Printer 1 Settings	
TagAdjustGap	40
TagAdjustLeft	5
TagAdjustTop	0
TagDPI	203
TagPrinter	
TagPrinterBurnSetting	15
TagPrinterType	Datamax
TagRetries	30
TagSensorMode	Black_Mark
TagSpecialBeginBatch	
TagSpecialEach	
TagSpecialEndBatch	
TagStopPosition	0

Godex TT361R (Either)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	10
TagAdjustTop	-20
TagDPI	203
TagPrinter	\\.\USB\VID_199F&PID_0001#10420250#(a5dcf10-6530-11d2-901f-00c04fb951ed)
TagPrinterBurnSetting	15
TagPrinterType	ZipTape
TagRetries	30
TagSensorMode	Black_Mark
TagStopPosition	15

Godex (Either)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	5
TagAdjustTop	12
TagDPI	203
TagPrinter	windows:Godex EZ-1100 Plus
TagPrinterBurnSetting	15
TagPrinterType	Godex
TagRetries	30
TagSensorMode	Default
TagSpecialBeginBatch	
TagSpecialEach	
TagSpecialEndBatch	
TagStopPosition	15

ZipTape ZT1300 (Either)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	6
TagAdjustTop	0
TagDPI	300
TagPrinter	COM3:
TagPrinterBurnSetting	12
TagPrinterType	ZipTape
TagRetries	30
TagSensorMode	Black_Mark
TagStopPosition	15

Zebra S4M (Dumbbell) (No Black Mark)

Tag Printer 1 Settings	
TagAdjustGap	5
TagAdjustLeft	-5
TagAdjustTop	-25
TagDPI	203
TagPrinter	lp1:
TagPrinterBurnSetting	25
TagPrinterType	ZPL
TagRetries	30
TagSensorMode	Edge_of_Label
TagStopPosition	0

Zebra Stripe 600 TT361R (Either)

Tag Printer 1 Settings	
TagAdjustGap	20
TagAdjustLeft	20
TagAdjustTop	-6
TagDPI	203
TagPrinter	com1:
TagPrinterBurnSetting	15
TagPrinterType	ZPL
TagRetries	30
TagSensorMode	Default
TagStopPosition	0